

Ceramic Pulley Installation Guide.

We recommend a qualified bicycle mechanic do all installations. Warranties can be voided if a qualified bicycle mechanic did not perform installation.

We recommend following the instructions from the manufacturer of your rear derailleur for setting cable tension, b-tension and limit screws. This information can be obtained from the manufacturer of your rear derailleur.

Pulleys should be mounted with the original allen bolts that came with your rear derailleur. It is advised to do a full re-adjust of your rear derailleur when installing our pulleys. This includes cable tension, b-tension and limit screws.

TIP: *You should keep your bearings well lubed and clean. Visit the “Bearing Maintenance” section of our tech pages.*

IMPROPERLY ADJUSTED REAR DERAILLEURS CAN CAUSE SIGNIFICANT DAMAGE TO YOUR BIKE, REAR DERAILLEUR AND REAR WHEEL BY THROWING THE CHAIN INTO THE SPOKES OR INTO THE FRAME.

WE HIGHLY RECOMMEND A QUALIFIED BICYCLE MECHANIC PERFORM ALL INSTALLTIONS.